

Attraction



Nail Enhancement System Instructions

For Professional Use Only

Attraction Acrylic Nail Enhancement System empowers the nail tech to create captivating enhancements, effortlessly. Highly advanced tri monomer and tri polymer technology gives the system its unique feel and spring back action, while delivering exceptional adhesion, unsurpassed strength and flexibility.

Natural Nail Prep

Proper preparation of the natural nail and workstation are preventative steps to guard against problems and will help you get the best possible results from your professional nail service.

1. Spray your hands and clients hands with Sanitize and gently massage. Sanitize will help reduce the spread of infection.
2. Apply a very small dollop of NSI's Vanish cuticle dissolve to each cuticle and gently massage. Gently push back the eponychium, and remove any non-living tissue. Wipe excess Vanish from each nail, using a Nail Wipe moistened with NSI Cleanse.
3. Remove the shine from the natural nail using NSI Prep 180 grit file following the contour of the nail and moving the file in the direction of nail plate growth.
4. Remove excess dust with the NSI Plush Brush.
5. Using an NSI Nail Wipe saturated with Nail Pure Plus, press and rub into natural nail, sidewalls, and under free edge to remove oil, moisture, and contaminants. Allow natural nail to become chalky white.
6. If extensions are desired, adhere tip or fit form at this time.
7. Apply Attract Acid-Free Primer liberally to the natural nails. Remove the brush from the bottle and wipe along the edge of the bottle, then brush onto two natural nails. Re-dip the brush and repeat the process until the nails are coated. Allow to dry for one minute. They will not appear chalky white.

Mix Ratio

1. Submerge brush completely into dappen dish of monomer and flatten hairs to saturate brush. This will prevent dry powder particles on the nail and it will force out any oxygen trapped around the brush hairs. Complete saturation is recommended at the beginning of each service.
2. Wipe the brush along the sides of the dappen dish to release excess liquid. The more liquid you remove the smaller the bead pick up, while still maintaining a medium wet mix. Leave larger amounts of liquids for larger beads that may be required.
3. Dip the flags (the very tip of the brush) into the powder. Hold and press until desired bead size has been achieved. The bead should be medium wet, looking slightly frosted and dimpled with no loose powder. When the bead is placed on the nail, it should level about 25 % and when it is pressed, it should move where you want it without running all over or being unable to press. Mix ratio can vary for the best results and it may have to be altered slightly depending on the weather conditions for your area. Use your eyes to see that the color looks correct, and your touch to determine the "feel" of the bead.
4. When dropping the bead on the nail, lift your brush for a brief moment and then gently press the bead. Continue pressing it from side to side to evenly distribute product.

Zone 1 Smile Line and Extension

Using Radiant White Powder or Soft White Powder

1. Use the mix ratio method above.
2. Place a medium sized bead near the smile line in zone 1, and using the tip of the brush, gently press the smile line into place guiding and slightly pushing the products into the corner of the smile line. Keep the brush handle angled downward which will help to keep the smile line edge thicker and will also taper the extension edge.

3. Clean any excess product from your brush and roll into a point. To crisp and define the smile line, back brush while the product is still moveable.

Zone 2 and 3 using Radiant Pink Powder or Pink Masque Powder

1. Use the mix ratio method above.
2. Drop the bead just slightly beyond the smile line, without overlapping or touching the smile line.
3. Press gently from side to side to coat the nail evenly. Very lightly, feather into the smile line. Be careful not to drag product over the white smile line. The intensity of the pink and the opacity will cover or camouflage the white.
4. Continue into zone 3, leaving a tiny margin around the cuticle and sidewalls. This will assure that you are not overexposing your client.
5. If additional product is needed to create the apex, use a small bead of Totally Clear in zone 2.
6. Allow product to set, until you hear a "click".

Zone 1, 2, or 3, one color using Totally Clear Powder or Sheer Pink Powder

1. Use the mix ratio method above.
2. These powders are sheer or clear and can be used in all 3 zones.
3. These powders can also be dragged over the smile line without camouflaging the whites.
4. Allow product to set, until you hear a "click".

Finishing

1. Using an NSI Black Cushion 180/240 Grit File, define the shape which is the outer edge, along the sidewalls and extension edge.
2. Refine surface and check for proper design and apex placement.
3. Remove excess dust with NSI Plush Brush.
4. Buff to a high shine with the NSI ProShine 1000/4000 Grit File or the NSI 3-Way Shiner.
5. Condition surrounding skin with Nurture Oil

OR

1. Follow steps 1, 2, and 3 above.
2. Apply Glaze 'n Go or Perma Gloss following the directions on the packaging.
3. Condition surrounding skin with Nurture Oil.

Cautions

Do not apply products to damaged, injured or inflamed cuticles or fingers. Avoid touching skin with product... Discontinue use if skin or nail irritation occurs. Avoid eye contact. Keep all products out of children's reach. Use in well-ventilated area. Accidentally spilled products on skin or clothing should be flushed with water and washed with soap. Rinse thoroughly. Consult your local government as to accepted form of waste disposal for all chemical products. In case of emergency, retain packaging and contact a physician immediately. For emergency medical information, contact Infotrac Chemical Emergency Response at 1-800-535-50553 or 1-352-323-3500.

Made in USA by NSI

W. Conshohocken, PA 19428

Tel: 800.354.6741 • 610.825.1524 • Fax: 610.825.2738

www.nsinails.com

NARITAWEG 165, 1043 BW AMSTERDAM, NL